



USER MANUAL

MBT

[MBT-165] 30.165.000 - [MBT-350] 30.350.000

THERMOBILE

 **EN** | English





TABLE OF CONTENTS

| | | | | | |
|-----------|---|-----------|-----------|---|-----------|
| 1 | Introduction | 5 | 14 | Burner maintenance | 32 |
| 2 | Technical specifications | 6 | 14.1 | Burner settings | 33 |
| 3 | Dimensions | 7 | 14.2 | Nozzle | 33 |
| 4 | Precautions and safety instructions | 8 | 14.3 | Fuel pump | 33 |
| 4.1 | General rules | 8 | 14.4 | Fan | 33 |
| 4.2 | Use | 8 | 14.5 | Photocell | 33 |
| 4.3 | Installer information | 8 | 14.6 | Fuel supply | 33 |
| 4.4 | User Information | 8 | 14.7 | Opening the burner | 33 |
| 5 | Description of the product | 9 | 14.8 | Burner control unit diagnosis and reset | 34 |
| 5.1 | General | 9 | 15 | Decommissioning | 35 |
| 5.2 | Identification | 9 | 15.1 | Switching off the boiler | 35 |
| 5.3 | Main components | 10 | 15.2 | Switching off the power | 35 |
| 6 | Transport and installation | 14 | 15.3 | Emptying the system | 35 |
| 6.1 | General | 14 | 16 | Faults and repairs | 37 |
| 6.2 | Truck | 14 | 16.1 | PLC faults | 37 |
| 6.3 | Trailer | 14 | 16.2 | Burner faults | 38 |
| 7 | Installation & Fuel supply | 13 | 16.3 | Other faults | 42 |
| 7.1 | Installation | 14 | 17 | Environment | 42 |
| 7.2 | Fuel tank | 15 | 17.1 | Antifreeze (propylene glycol) | 42 |
| 8 | Commissioning | 16 | 18 | Dismantling and disposal | 42 |
| 9 | General operation | 16 | 19 | EC declaration of conformity | 42 |
| 10 | Main controls | 16 | | | |
| 11 | HMI Control panel | 18 | | | |
| 11.1 | Layout of the HMI | 18 | | | |
| 11.2 | Menu structure | 18 | | | |
| 12 | Functionality of safety components | 25 | | | |
| 12.1 | Fire valve | 25 | | | |
| 12.2 | Maximum thermostat | 25 | | | |
| 12.3 | Pressure relief valve (5Bar) | 25 | | | |
| 12.4 | Automatic de-aerator | 26 | | | |
| 12.5 | Upper and lower pressure switches | 26 | | | |
| 13 | Maintenance and maintenance schedule | 27 | | | |
| 13.1 | Boiler pressure refill | 27 | | | |
| 13.2 | Cleaning the oil filter | 28 | | | |
| 13.3 | Cleaning the water filter | 29 | | | |
| 13.4 | Maintenance components | 30 | | | |
| 13.4 | Opening and cleaning the boiler | 31 | | | |



1 INTRODUCTION

This MBC-500 manual is intended for professional end users such as installers and rental companies who manage the installation, maintenance and transport themselves.


The MBC-500 is a hot water installation with a maximum power of 500 kW.

Applications:

Temporary replacement in case of failure of the existing installation. Temporary heating of new construction and renovation projects and process heating. Heating for events, heating of sports fields during winter periods.

A supply temperature is set on the boiler for the heating circuit. The oil burner first heats up the boiler. An internal/external circulation pump pumps water through the boiler to transport the produced heat to the required location. A three-way valve controls the water flow to ensure a stable supply temperature in the circuit.

01



1 - Burner

2 - Three-way valve

3 - Pump

Explanation of pictograms in this manual:

**CAUTION!**

Indicates a risk of equipment damage.

**WARNING**

Indicates a dangerous situation, which death or serious injury may result.

**WARNING**

Indicates the possibility of fatal shocks.

**HOT**

Indicates a hazardous surface temperature.



Suggestions and tips to simplify the performance of the relevant tasks or actions.



2 TECHNICAL SPECIFICATIONS

| General specifications | | MBT-165 | MBT-350 |
|--|----|---------|---------|
| Net capacity | Kw | 100-165 | 200-350 |
| Efficiency | % | >95 | >95 |
| Temperature difference between flow and return in the boiler | °C | 20 | 20 |
| Max. outlet temperature | °C | 90 | 90 |

| Boiler specifications | | MBT-165 | MBT-350 |
|-----------------------|--|------------|------------|
| Manufacturer | | Riello | Riello |
| Type | | RTS 166 3S | RTS 349 3S |

| Burner specifications | | MBT-165 | MBT-350 |
|-----------------------------|--------------|------------------|------------------|
| Manufacturer | | Riello | Riello |
| Burner type | | RL 22 BLU | RL 44 |
| Fuel type | | Diesel, HVO, GTL | Diesel, HVO, GTL |
| Pump pressure | Bar | 10 - 23 | 12 |
| Nozzle Danfoss | USG/h/degree | 1x 2.25 GPH 60° | 2x 3.5 GPH 60° |
| Fuel tank capacity | l | 700 | 1500 |
| Fuel consumption | l/h | 10/16 | 17/35 |
| Max. gas oil fuel viscosity | cST mm²/s | 6 | 6 |
| Max. outlet temperature | °C | 220 | 220 |

| Emission values | | Low | High |
|-----------------|--------|------|------|
| CO ₂ | % | 12,5 | 12,5 |
| CO | PPM | <10 | <10 |
| O | % | 4 | 4 |
| NOx | mg/kWh | <120 | <120 |


| Hydraulic specifications | | MBT-165 | MBT-350 |
|---|------|---------------|---------|
| Liquid flow | m³/h | 7 | 15 |
| System volume (excl. expansion vessel) | l | 340 | 510 |
| Expansion vessel volume | l | 140 | 200 |
| Max. system pressure | Bar | 5 | |
| Fluid | | non-corrosive | |
| Pressure loss @25 m³/hr - w. clean filter | kPa | 45 | |

| Electrical specifications | | MBT-165 | MBT-350 |
|---------------------------|----------|-------------|-------------|
| Supply voltage | V | 230 1ph | 230 1ph |
| Frequency | Hz | 50 | 50 |
| Amperage | A | 5 | 6 |
| Voltampère | kVA | 2 | 2 |
| Electrical connection | Cee-form | 16A 1P N PE | 16A 1P N PE |

| Noise specifications | | MBT-165 | MBT-350 |
|--------------------------|-----|---------|---------|
| Sound pressure level @5m | dBA | | |

| Physical specifications | | MBT-165 | MBT-350 |
|-----------------------------|---------------|--------------|--------------|
| Overall length [A] | mm | 4350 | 4850 |
| Overall width [B] | mm | 2280 | 2280 |
| Overall height [C] | mm | 2660 | 2680 |
| Total weight | kg | max. 2700 | max. 3500 |
| Fluid connection (cam lock) | Inch | 2 | 2 |
| Chimney connection | mm | 250 | 300 |
| Fuel connection | Quick connect | 0,5" | 0,5" |
| Stackable | | Not possible | Not possible |

3 DIMENSIONS



4 PRECAUTIONS AND SAFETY INSTRUCTIONS

4.1 General rules

This document contains important information for the safe and confident installation, use and dismantling of the boiler.

The activities described in this manual are intended to be performed by authorised and trained staff only. The MBC-500 is intended for professional use. Unqualified staff are not permitted to operate or maintain this device. The warranty is only valid if original components are used for repairs.

4.2 Use

The Thermobile MBC-500 can be used to supply closed systems with warm or hot water.

4.3 Installer information

Only use the device for the purpose described in this manual. The manufacturer shall not be held liable for the consequences of incorrect or illogical use. Incorrect use may cause damage to the device and/or create hazardous situations.

The installation and packaging materials may be hazardous, so keep them away from children.

Never modify the device or any part of it without a certificate of approval from the manufacturer, otherwise you and others may be seriously injured. Significant property damage may result. All repairs must be performed using original components.

Ensure that work is always performed according to the regulations of the local authorities.



CAUTION

Do not lift or hoist the boiler, this may damage the boiler system.

4.4 User information

Inform the user about the operation of the device. A manual must always be available near the boiler.

The user must check the system pressure of the device regularly.

Never change the burner settings without the use of a flue gas meter.

Pay close attention to the warnings in this manual.

5 DESCRIPTION OF THE PRODUCT

5.1 General

The Thermobile MBT is a water heater with a low and high stage. This boiler must be filled with water or a max 30%water/propylene glycol mixture.The circuit consists of a Riello boiler and stainless steel piping. By means of a three-way valve, the correct temperature is obtained.

The boiler circuit is an open circuit with 2' camlock connections and a water filter. The three-way valve in the primary circuit is controlled based on the outgoing temperature of the circuit. This control uses PI&D.

The temperature can be set using an interface located in the boiler. Here, the boiler can also be switched on or off.

The system is protected with a pressure relief valve, pressure switches, maximum temperature sensor and a fire valve in the fuel supply.



5.2 Identification

MBT 350kW

| | | | |
|-------------------|----------|-------------------|---------------|
| Net Capacity High | : 350 kW | Efficiency max. | : 95.5% |
| Net Capacity Low | : 175 kW | Efficiency at 30% | : 98.5% |
| P safety | : 5 Bar | T out | : 5°C to 90°C |
| V total | : 700L | Q minimum | : 20 m3/h |

| | |
|------------------|--------------------|
| Fuel types | : Diesel, HVO, GTL |
| Fuel consumption | : max. 36L/h |
| Fuel pressure | : 12Bar |
| Electrical Input | : 230V~ 50Hz |
| Max current | : 12A |
| Average current | : 6A |
| Weight empty | : 2200kg |
| Operating range | : -5°C to 40°C |
| Storage temp. | : 5°C to 40°C |


Prod.code. 30350020 REV00

  Fabr.year 2024 Serial nr : 2404602

Made by THERMOBILE Industries The Netherlands


03

04



5.3 Main components


- | | |
|--|------------------------------|
| 1. Cabin fan | 10. Max. pressure protection |
| 2. Maximum thermostat | 11. Fuel tank |
| 3. Connection group expansion vessel | 12. Anti siphon valve |
| 4. Pressure relief valve | 13. Three-way valve |
| 5. Expansion vessel | 14. Automatic air vent |
| 6. Flue gas outlet | 15. Boiler |
| 7. Convector heater / Frost protection | |
| 8. Fill / drain boiler | |
| 9. Min. pressure protection | |



- 16. Venting ball valve
- 17. Venting ball valve
- 18. Antenna
- 19. Control panel AHW boiler
- 20. Switch box AHW boiler
- 21. Butterfly valve return connection external

- 22. Water pump
- 23. Water filter
- 24. Butterfly valve return connection
- 25. Butterfly valve supply connection
- 26. Burner


06



- 27. Siemens S400 controller
- 28. Calculus C06
- 29. Earth leakage circuit breaker B16 30mA
- 30. Circuit breaker 6A B
- 31. Circuit breaker 6A C
- 32. WCD 230V
- 33. 24V power supply
- 34. Thermostat connection
- 35. Light switch

- 36. 230V plug
- 37. Main switch
- 38. USB connection ext.
- 39. IO Relay 230V
- 40. Lamp (Yellow)
- 41. Switch
- 42. Lamp (Red)
- 43. Siemens display

07



- 44. Tigerloop
- 45. Oil filter internal
- 46. Oil three-way valve
- 47. Fire valve
- 48. Oil filter external

6 TRANSPORT AND INSTALLATION

6.1 General

The MBT is built into a closed trailer and can be moved using a vehicle with a towbar or truck. This unit is fully assembled, tested and ready to use. Shocks must be avoided at all times during transport. Heavy shocks or excessive tilting of the unit can cause damage or a hazardous situation. Always place the boiler on a firm and stable surface that is suitable for the boiler when it's in operation. Always place the boiler on a horizontal plane. Ensure that there is always a gap of 1 metre free of obstacles around the boiler.

6.2 Truck

Ensure that the boiler is correctly secured to the truck or trailer according to the applicable regulations.

6.3 Trailer

When transporting a trailer, it is essential to follow the applicable rules and guidelines applicable to this type of equipment. Ensure that transport is safe and compliant. For additional information and specific instructions, please refer to the manufacturer's manual.

Also make sure there is no water left in the heating system. Check this before transport and drain the water if necessary.

- Make sure the support wheel is fully screwed in and jacked up before driving. Otherwise the nose wheel may break off, become loose or block the brake system block.
- Attach the safety cable around the coupling of the towing vehicle.
- Close the double wing door or access door securely before driving.
- Comply with the applicable legislation of the respective country for driving with a trailer combination.
- Remove ice, snow and water from the roof of the trailer, regardless of whether the trailer is in use. Ice, snow and water accumulations can cause damage to the roof and cause danger in traffic.

7 INSTALLATION & FUEL SUPPLY

7.1 Installation

WARNING



This device must not be lifted or hoisted. Only use the appropriate means of transport.

CAUTION



The installation and commissioning may only be performed by qualified staff.

Do not drive the trailer if the fuel tank contains more than 200 litres of fuel. Otherwise, the permitted total weight of the trailer will be exceeded. Pump off excess fuel before transporting the trailer.


CAUTION




When transporting the system, make sure the support wheel is turned upwards!

1. Place the container horizontally/level on a solid and flat surface. Ensure that the exhaust gases escaping from the chimney don't cause any hazards or nuisance. Observe the local regulations. Ensure unimpeded access to the system.


2. When using an external fuel tank, connect it to the hydraulic quick coupler with a suitable pipe. See fig. 08



3. Open the fuel tap on the filter. See fig. 9. 1: Internal tank, 2: External tank.



4. Close the circuit by connecting hoses to the supply and return or use the secondary return connection with an external pump. Always ensure that the pump is connected as close as possible to the boiler return inlet. See fig. 10. 1: External pump, 2: Internal pump.



5. Check that the circuit is pressurised. If the pressure is not sufficient, top it up first. See 14.1 for more information.

6. Finally, connect the mains power supply.

7.2 Fuel tank

The boiler is equipped with an internal fuel tank with anti-siphon valve and a built-in level sensor. For situations where a larger fuel capacity is required, an external fuel tank can be connected to the available quick connector, see 7.1 (2).

Depending on the type of valve, the changeover to the external fuel tank must be performed manually or via the controller. For an automatic valve, the switchover is set via the controller. For a manual valve, the switchover should be performed manually.

CAUTION



While using an external fuel tank, close the filter of the internal fuel tank to prevent possible leakage.

8 COMMISSIONING

**CAUTION**

For correct operation, ensure that the circuit is correctly filled with water.

1. Energise the system by turning on the main switch.
2. Control takes place automatically with a PLC. The PLC is switched on by turning the black switch button under the display to 'I'. This will heat the boiler to a minimum internal temperature and switch on the internal pump.

**CAUTION**

The internal pump remains on until the boiler power supply is cut off.


Detailed operation and settings of the system follow in the following chapters (9, 10 and 11).

9 GENERAL OPERATION

The main controller consists of physical buttons, switches and lights. (main power, start/stop, general alarm and controller with display)

10 MAIN CONTROLS

11





The physical controls of the boiler consist of two switches, two lights and a controller with a display. For each control component, the text below describes what it is for.

Digital controller (Screen)

The digital control of the boiler, for more information see chapter 11 'HMI CONTROL PANEL'.

Start/Stop: (Black switch)

When the switch is set to ' I ', the boiler will start operating. At the first start, after the machine is energised, the internal circulation pump will start running. The burner will turn on to reach the desired temperature. First, the burner will evaporate any condensate present, after which the control valve of the primary circuit will operate. The control valve regulates the outgoing temperature of the circuit. When the switch is set to ' 0 ', the burner will turn off and the control valve will be fully open for the set lag time. During this lag time, the boiler will be optimally cooled. The circulation pump of the primary circuit remains in operation as long as voltage remains on the machine.

Power ON: (Yellow)

The 'Power on' lamp lights yellow when there is power on the machine. This means that the controller's power supply is working properly and the power plug is connected correctly.

Alarm: (Red)

The 'Alarm' lamp comes on when the boiler goes on malfunction. With this alarm, the cause of the malfunction must be checked carefully.


The maximum thermostat must be manually reset at the back of the boiler, see 13.2. An alarm is automatically reset when the cause is remedied.

Main Power:

De "Main Power" schakelaar onderbreekt de stroomtoevoer. In stand "O" wordt de stroom onderbroken en is het lampje "Power on" uit. De machine is spanningsvrij vanaf de schakelaar en er kan dus veilig aan worden gewerkt.

11 HMI CONTROL PANEL

11.1 Layout of the HMI




- 1.** Home button: Use this button to return to the main overview or Service menu.
The LED of this button lights up green when the boiler is switched on
- 2.** Alarm button: used to display an alarm or manually reset an alarm.
Red LED illuminates when an alarm is detected
- 3.** Escape key: return to the previous page.
This LED flashes green when the pump is switched on.
- 4.** Up arrow: Used to move from line to line in the currently displayed screen and to change the setting of a parameter.
- 5.** Down arrow: Enables management of the currently displayed screen and setting values of parameters.
- 6.** Enter button: Used to confirm choice like, menu selection, confirm parameter or log in. Logging in can be done by pressing this button for 3 seconds.

11.2 Menu structure

11.3.1 - Main overview before login

de Main overview heeft verschillende niveaus, standaard krijgt een gebruiker het basis menu te zien


Overview

Navigate to the Overview Page to view system status and temperature settings.

Information


Navigate to the Information Page to access operational data and statistics.

11.2.2 - Login

Login by pressing enter for 3 seconds. See login screen. Enter the 6-digit code here, change the first number of the code with the arrow keys and move to the next one with the enter key.

11.2.3 - Main overview after login


The Main Menu serves as the central navigation hub for accessing various parameters and settings of the boiler system. From this page, users can navigate to different sections to monitor, configure, and manage system operations.



- Overview**
Navigate to the Overview Page to view system status and temperature settings.
- Settings**
Navigate to the Settings Page to configure system parameters for heating control.
- Information**
Navigate to the Information Page to access operational data and statistics.
- Service menu**
Navigate to the Service Menu Page for advanced system settings and configurations.

11.2.4 - Main overview - Overview

The Overview Page provides a comprehensive display of critical system information, including operational status, temperature settings, and sensor readings for both primary and secondary circuits.



- Plant status**
Displays the current operation mode of the system.
- Fault**
Indicates current system faults (e.g., burner or pump issues).
- Floor heating mode**
Enables floor heating protection mode with a maximum supply temperature limit.
- Setpoint supply temp**
Sets the target supply temperature for the system.
- Circuit Temps**
Displays parameters related to the circuit.
- Supply temp.**
Sensor reading for the secondary system supply temperature.
- Return temp.**
Sensor reading for the secondary system return temperature.



| Overview | 1/19 |
|------------------------|---------|
| Primary circuit | |
| Boiler Temp. | 22.2 °C |
| Return temp. | 22.1 °C |
| Pressure | 0.0 |
| Pressure Status | Fault |
| Internal Fuel tank | 0 |
| Internal/External Tank | 1 |

Primary circuit

Displays parameters related to the primary circuit.

Boiler Temp.

Sensor reading for the primary system supply temperature.

Return Temp.

Sensor reading for the primary system return temperature.

Pressure

Digital pressure reading of the system.

Pressure Status

Status of the min/max pressure switches.

Internal Fuel tank

Displays the current level of the internal fuel tank.

Internal/External Tank (Option)

Valve status for switching to external fuel supply
(ON = external tank).

Pump Status

Indicates the current command status of the pump (On/Off).

Burner

Indicates the current status of the burner (On/Off).

Burner Stage 1

Indicates the status of burner stage 1 (low stage).

Burner Stage 2

Indicates the status of burner stage 2 (high stage).

Mixing Valve

Displays the current position command of the mixing valve.

| Overview | 1/19 |
|----------------|---------|
| Pump status | Off |
| Burner | Off |
| Burner Stage 1 | Off |
| Burner Stage 2 | Off |
| Mixing valve | 100.0 % |

11.2.5 - Main Overview - Settings

The Settings Page allows users to configure system parameters for controlling the heating process, including burner operation, temperature limits, and pump delays.

| Settings | 1/25 |
|---------------------|---------|
| Burner start 1 | 3.5 °C |
| Burner stop 1 | 3.0 °C |
| Burner start 2 | 5.0 °C |
| Burner stop 2 | 4.0 °C |
| Burner timeout | 15 s |
| Burner setp. offset | 15.0 °C |
| Burner setp. max | 95.0 °C |

Burner start 1

Temperature difference to start the low-stage burner.

Burner stop 1

Temperature difference to stop the low-stage burner.

Burner start 2

Temperature difference to start the high-stage burner.

Burner stop 2

Temperature difference to stop the high-stage burner.

Burner timeout





Minimum stop time before the burner can restart.

Burner setp. offset

Offset temperature for the boiler.

Burner setp. max

Maximum boiler temperature limit.

| Settings | 1/25  |
|---|--|
|  Burner delay | 0 s |
| Temp. circ. release | 50.0 °C |
| Follow-up time | 15 s |
|  Pump delay | 5 s |
| Tank min. | 100 l |
| Tank max. | 396 l |
|  Valve min. pos. | 50.0 % |

Buner delay

Delay time for switching the burner relay after a heat request.

Temp. circ. release

Release temperature for the circuit.

Follow-up time

Duration the three-way valve remains open during system shutdown.

Pump delay

Delay time for switching on the pump relay.

Tank min.

Volume setting to switch from internal to external tank.

Tank max.

Volume setting to switch from external to internal tank.

Valve min. pos.

Minimum valve position.

Valve max. pos.

Maximum valve position.

Min. setp. supply

Minimum limit for the supply temperature setpoint.

Max. setp. supply

Maximum limit for the supply temperature setpoint.

Source temp.

Temperature probe used for the PID controller.

Sp. flow temp.





Setpoint supply temperature.

Burner Cooldown

Delay time for restarting the burner after a shutdown.

Floor heating max. temp.

Maximum temperature during floor heating mode.

| Settings | 1/25  |
|---|--|
|  Valve max. pos. | 100.0 °C |
| Min. setp. supply | 0.0 °C |
| Max. setp. supply | 100.0 °C |
|  Source temp. | TFI |
| Sp. flow temp. | 76.9 °C |
| Burner | 15 s |
|  Floor heating max ... | 40.0 °C |

PID

Adjust proportional, integral, and derivative control settings.

Valve kP




Proportional gain for PID control.

Valve Ki

Integral time for PID control.

Valve kd

Derivative time for PID control.

| Settings | 1/25  |
|--|--|
|  PID | |
| Valve kP | 2 |
| Valve Ki | 60 s |
|  Valve kd | 0 s |

11.2.6 - Main Overview - Information

The Information Page displays operational data and statistics, including burner runtime, pump status, and fuel tank levels.

| | |
|-----------------------|------|
| Information | 1/12 |
| Burner | |
| Running hours stag... | 1 h |
| Numb. starts stage... | 0 |
| Running hours stag... | 0 h |
| Numb. starts stage... | 0 |
| Pump | |
| Run cmd hours | 1 h |

Burner

Displays burner-related information.

Running hours stage 1

Hour counter for burner stage 1 (low stage).

Numb. starts stage 1

Number of starts counter for burner stage 1 (low stage).

Running hours stage 2

Hour counter for burner stage 2 (high stage).

Numb. starts stage 2

Number of starts counter for burner stage 2 (high stage).

Pump

Displays pump-related information.

Run cmd hours

Pump command run hours.

| | |
|-----------------------|---------|
| Information | 1/12 |
| Oil supply | |
| Tank | 0 |
| Solenoid valve tank | 1 |
| Mixing valve position | 100.0 % |

Oil supply

Displays fuel tank and valve status.

Tank

Current internal tank level (if tank sensor is connected).

Solenoid valve tank

Solenoid valve status for internal/external tank switching.

Mixing valve position

Mixing valve position command (0-100% = 0-90°).

11.3.7 - Main Overview - Service menu

The Service Menu Page provides access to advanced system settings and configurations, including PLC information, system configuration, and interface settings.

| | |
|----------------|-----|
| Service menu | 1/3 |
| System objects | |
| Configuration | |
| Interface | |

System objects

Navigate to the System Objects Page for PLC information and settings.

Configuration

Navigate to the Configuration Page to change system configuration.

Interface

Navigate to the Interface Page to modify PLC inputs and outputs.

11.2.8 - Main Overview - Service menu - System objects

The System Objects Page displays system information, including time settings, communication configurations, and diagnostic data.

System objects

14:02:37

Date/time settings

Restart

Communications

Plant info

Versions

Save / load

1/14

8↔

18.02.25

▶

▶

▶

▶

▶

▶

✓

- System clock**
Displays the current system time/date.
- Date/time settings**
Change time settings.
- Restart**
Restart the system.
- Communications**
Configure communication settings (e.g., IP address).
- Plant info**
Displays plant information.
- Versions**
Displays system version information.
- Save / load**
Options for saving and loading settings and parameters.

System objects

Archive

System alarms

Diagnostic

Alarming

PIN handling

HMI

Language selection

1/14

8↔

▶

▶

▶

▶

▶


▶

English

- Archive**
Configure archive settings.
- System alarms**
Displays system alarm information.
- Diagnostic**
Access controller diagnostic information.
- Alarming**
View alarm history and settings.
- PIN handling**
Change login PIN settings.
- HMI**
Configure HMI settings.
- Language selection**
Select the language for the HMI interface.

11.2.9 - Main Overview - Service menu - System objects - Save / Load

The Save/Load Page allows users to save and load system settings and parameters, including alarm history and firmware updates.



+External memory

Displays the status of external memory.

Formatting

Format USB drive (all data will be deleted).

Free memory [MB]


Displays the amount of free memory on the USB drive.

Sett.save -> Ext.m.

Save system settings and parameters to the USB drive.

Sett.load<- Ext.m.

Load system settings and parameters from the USB drive.



Filter

Filter for partial save/load settings.

Restart required !

Restart the controller after loading new settings/parameters.

Alarml.save->Ext.m

Save alarm history to a TXT file on the USB drive.

BSP load


Load new BSP firmware file to the controller.

Sett.service load

Load service settings.

Sett.factory load

Load factory settings.



Sett. service save

Save current settings as service settings.

Save application

Save application to internal memory.

12 FUNCTIONALITY OF SAFETY COMPONENTS

12.1 Fire valve

The fire valve is located in the fuel supply line. The fire valve has a temperature sensor mounted on the ceiling of the boiler. When the temperature rises to 90°C, the fuel supply to the burner is cut off. This prevents possible uncontrollable leakage due to an excessively high temperature inside the device.

If the fire valve is triggered, the reset button must be operated manually. Fig. 13 shows the open and closed position of the fire valve


CAUTION

Once the fire valve has been triggered, the heat source and its cause must first be investigated before resetting the fire valve.

13


OPEN

Reset →



CLOSED

Reset →



12.2 Maximum thermostat

The boiler is protected internally against overheating. Overheating is very hazardous in a boiler because high pressure can arise in the boiler and the connected pipes.

The maximum thermostat is located at the back of the boiler and can be accessed through the side door. After the boiler has been secured and cooled down, the maximum thermostat can be reset by removing the protective cover of the thermostat and pressing the green button with a pointed object. The reset procedure is successful when a clicking sound is heard.

14




CAUTION

If the temperature sensor in the boiler has not cooled down sufficiently, resetting the maximum thermostat is not possible.

12.3 Pressure relief valve (5Bar)

There is a pressure relief valve in the circuit. If the pressure rises above 5 Bar in the circuit, the valve will open and discharge the excess water.

15




WARNING!

Hot water and steam will often be released during an overpressure. Never work in the boiler when it's hot. Always ensure that you keep an eye on the pressure gauge in the expansion vessel and stop working in the boiler at a pressure above 3 bar.


**12.4 Automatic de-aerator**

In the boiler's complex piping system during filling, air bubbles can accumulate. Over time, the air bubbles will move to the top of the boiler.

Air in the primary circuit can cause irregular flow and pressure. It's important to ensure that as little air as possible is inside the boiler and the primary circuit. To remove these air bubbles from the system, an automatic de-aerator is located on top of the boiler. (fig. 16)

**12.5 Upper and lower pressure switches**

There is both an upper and a lower pressure switch on the circuit. These can be found side by side on the top of the circuit. (fig. 17)



The upper or lower pressure switches switch when the primary pressure falls outside the range of 0.5 to 4.5 Bar.

In case of activation, the switches automatically reset when the problem is corrected.

13 MAINTENANCE AND MAINTENANCE SCHEDULE

**WARNING!**

Before performing maintenance or repairs, always disconnect the boiler from the power supply

**WARNING!**

During and after operation, the opening of the chimney and the camlock connections for the circuit are hot.

13.1 Boiler pressure refill

It is important that the circuit has a pressure above 0.5 Bar at all times. Thermobile maintains a filling pressure of 1.5 Bar at 20°C. There is a pressure gauge on the expansion vessel to read the system pressure.

18

**CAUTION**

When using the boiler in larger installations, the integrated expansion vessel may not provide sufficient capacity. Check whether an additional expansion vessel is necessary and, if necessary, consult an installer or specialist for advice.



19



If the pressure is too low, it can be topped up via the connection (filler tap) at the bottom of the boiler. The connection is located on the right-hand side of the trailer. See 'Fig. 19'.

Use a sturdy hose to refill the boiler.

Allow the hose to fill with water as much as possible before connecting it. Remove the cap from the filling valve. Then connect the hose to the filling valve.

Turn on the water supply of the hose gently, then open the filling valve in small increments until the pressure starts to rise on the pressure gauge. Once the desired pressure has been reached, the filling valve must first be closed, then the water supply must be cut off.

CAUTION

Always refill the boiler with clean tap water. It is preferable to supplement the boiler with demineralised water. This improves the life of the boiler.



13.2 Cleaning the oil filter

Many oil tanks are heavily contaminated. Especially if the tank is almost empty or if it is refilled during operation of the boiler, a lot of dirt from the burner can get into the fuel circuit filter. it.

If the filter is too dirty or appears to be dirty, clean it as follows:

1. Place a cloth or tray under the filter to catch any oil leaks.
2. Close the filter using the rotary knob on top of the filter.
3. Loosen the retaining ring of the filter cup and carefully remove the filter cup with the filter from the base.

6. Open the filter using the rotary knob on the filter.

7. After fitting, check that there is no leakage by briefly running the boiler until the filter cup is refilled with fuel.

TIP

Place a scraper filter on the fuel tank to avoid frequent cleaning of the oil filter. A scraper filter is many times easier to clean and can be used for several boilers.




WARNING!



Always wear gloves suitable for working with fuel while cleaning the oil filter.

20



4. Empty the filter cup into a suitable container for the fuel residue.

CAUTION



If you do not have a stainless steel filter, you cannot clean this filter and you need to replace it.

5. When the filter and filter cup are clean they can be refitted.

13.3 Cleaning the water filter


The boiler is equipped with a water dirt filter to protect the system from contamination.

The frequency of cleaning the filter depends on the water quality and the duration of the heating project. Check the filter regularly during use and clean or replace it if necessary to ensure optimal operation.


If in doubt about the cleaning frequency, we recommend inspecting the filter weekly, especially in environments with potentially contaminated water.

Clean the filter using the following steps:


1. Close the circuit with the two butterfly valves at the circuit connections.




2. Connect a hose to the bottom of the filter, then place the end of this hose in a suitable drain.



3. Open the tap on the filter to drain it .



4. When the system is completely empty, the filter can be removed by unscrewing the 4 bolts under the filter.





- 5. Take the filter gauze with jacket to a cleaning station and rinse the filter until no more dirt is present.
- 6. Replace the filter and fit the cover again with the 4 bolts.

CAUTION



Don't forget to install the cover gasket and replace it if necessary to prevent leakage.

13.4 Maintenance components

The components to be ordered for general maintenance are as follows:

MBT-165

| Component | Number | Interval |
|-------------------------|----------|---|
| Nozzles 2.25 gph 60gr S | 40504705 | Replace annually. |
| Oil filter | 41520027 | Clean as soon as soiled. |
| Flange Gasket DN 50 | 30500190 | Replace as soon as flange is removed or damaged |
| Flange Gasket DN 65 | 30500191 | Replace as soon as flange is removed or damaged |
| Camlock Gasket | 30500194 | Replace when disassembled is or annual. |

| Component | Interval |
|----------------|-----------------|
| Burner chamber | Clean annually. |

MBT-350


| Component | Number | Interval |
|---------------------|----------|---|
| Nozzles 3.50 60gr A | 30350102 | Replace annually. |
| Oil filter | 41520027 | Clean as soon as soiled. |
| Flange Gasket DN 50 | 30500190 | Replace as soon as flange is removed or damaged |
| Flange Gasket DN 65 | 30500191 | Replace as soon as flange is removed or damaged |
| Camlock Gasket | 30500194 | Replace when disassembled is or annual. |

| Component | Interval |
|----------------|-----------------|
| Burner chamber | Clean annually. |

13.5 Opening and cleaning the boiler

At least annually, the boiler must be cleaned and carbon residues removed. This is essential to extend the life of the boiler.


1. Remove the red cap from the boiler.




2. Unscrew the 6 bolts on the door.



4. Open the door.



5. Remove the flue gas inhibitors.



6. Clean the inside with a squeegee brush or other suitable tool.

15 BURNER MAINTENANCE

Extensive explanations and details of the installed burner can be found in the manual supplied by the manufacturer.


14.1 Burner settings

CAUTION




Adjusting the air supply must always be done in combination with a CO₂ measurement. It must always be between 12 - 12.5%.


29



30



31



| | MBT-165 | MBT-350 |
|---|----------|----------|
| A | 2 mm | 2 mm |
| B | 3.5-4 mm | 3.5-4 mm |
| C | 5 | 3 |

Nozzle

| | |
|---------|-----------------------|
| MBT-165 | 1x 2.25 gph 60gr S |
| MBT-350 | 2x 3.50/60A |

Pump pressure

| | |
|---------|--------|
| MBT-165 | 10 Bar |
| MBT-350 | 24 Bar |

14.2 Nozzle

Don't clean the nozzle opening. Never open the nozzle. The nozzle filter may be cleaned or replaced if necessary. Replace a nozzle every year or after 1,000 burning hours.

14.3 Fuel pump

The pump pressure should not deviate more than 0.5 Bar. Unusual noises from the pump indicate wear and tear. See 14.1 Burner settings for pump pressure.

If the pump pressure is unstable or the pump is too noisy, remove the flexible supply pipe from the oil filter. Use a local fuel supply to test if the problem lies in the pump or the supply oil filter.

If the problem lies in the pump, clean the oil filter of the pump. If the problem seems to be in the supply line, ensure that it's completely clean and that no air is being sucked in.

14.4 Fan

Check that no excess dust has accumulated in the fan or on the fan blades. If there's a lot of dust, the fan must be cleaned. Too much dust on the fan or in the fan housing can reduce the airflow, which can cause inefficient burning.

14.5 Photocell

Clean the glass housing of the photocell. Remove the photocell (1) to pull it out from the clamped position.




14.6 Fuel supply

Check regularly that the fuel supply to the burner is sufficiently clean. If there's a lot of water or dirt in the tank or pipes, they must be cleaned. Use an external pump to suck water and other impurities out of the tank.

Clean the tank every 5 years or when necessary.

14.7 Opening the burner

Open the burner and remove the burner chamber by following the steps below; the numbers correspond to the indications on the image.



1. Switch off the power to the boiler.
2. Remove the screw (1) with the protective cap (2) from the burner.
3. Remove the bolt (3) to slide the burner out of the burner pipe.
4. Place the extension sliding guides (4), if supplied, on the existing guides.
5. Pull part A back, taking care to keep the burner straight to prevent damage to the baffle plate (6)




14.8 Burner control unit diagnostics and reset

During startup, the signal lamp on the burner control unit lights up as follows:

| Status | Colour code |
|---|-------------|
| Pre-purification | ●○○●○○○○●● |
| Ignition phase | ●○○●○○○○●● |
| Operation, flame OK | □□□□□□□□ |
| Working with weak flame signal | □○□○□○□○□ |
| Power supply less than ~170V | ●▲●▲●▲●▲●● |
| Lock | ▲▲▲▲▲▲▲▲▲▲ |
| Extremely light | ▲□▲□▲□▲□▲ |
| ○ Off ● Yellow □ Green ▲ Red | |

The burner control unit has a diagnostic mode for easy identification of the causes of burner faults (Indicator: RED LED).

To use this function, wait minimum 10 seconds after the start of the safety condition (Lock-out). Then press down the reset button for more than 3 seconds. The burner control unit generates a sequence of pulses (1 second apart) that are repeated at an interval of 3 seconds. After identifying the fault through the pulses, the system must be reset by pressing down the button for between 1 and 3 seconds.



The codes with associated faults are shown in the table in chapter 17.2 Burner faults.

15 DECOMMISSIONING
15.1 Switching off the boiler

Always switch off the Boiler by using the 'Start/Stop' switch. When the switch is set to stop, the unit starts post-cooling. The set post-cooling time determines the time the three-way valve is fully opened to allow the unit to cool down as quickly as possible. During this process, let the circuit run to dissipate the heat.

CAUTION

Always leave the unit to cool down below 50°C before taking any other actions. After the "Stop" of the boiler, the internal circulation pump will always continue to run as long as the boiler is under voltage. Running the pump ensures good mixing of the liquid and prevents the liquid from freezing during the winter period.


CAUTION

If the boiler has been de-energised by power failure, or manually turning off the main switch, the pump will not start running again until the 'Start/stop' switch is turned on.


15.2 Turning off the power

To make the boiler completely de-energized, the main switch must be turned to 0. This switch must be blocked with a lock during maintenance on the device.

To be able to work completely without voltage in the switch box, the mains plug must be disconnected.

After performing these actions, it's safe to work on the boiler.

15.3 Emptying the system

To make changes or repairs to the circuit, it must be emptied.


CAUTION


Always ensure that the boiler has cooled down completely before emptying or disconnecting the system.


WARNING!


The primary circuit has an expansion vessel and the circuit is pressurized under normal conditions. In the event of leakage or disconnection of the pipes, high-pressure liquid can be released.

On the right side is the circuit filling point. Connect a hose to the filling point and place the other end of the hose in a suitable drain or drain tank.


34


Gently open the tap until liquid comes out of the hose.

35


Fluid flow will decrease as the pressure of the circuit decreases.

When the pressure has decreased and the liquid flow is minimal, the ball valve on top of the boiler can be opened to allow the liquid to flow better.



To empty the system more quickly, you can also use a suitable pump and hose.

**CAUTION**

Dispose of the water/glycol mixture according to the regulations of the local authorities.

16 FAULTS AND REPAIRS

Faults can occur in different components of the boiler.

There are only 2 components on the boiler that can visually indicate malfunctions. The display and burner inform the user through image and light signals that a malfunction is present during operation.

16.1 PLC faults

| Description | Cause | Solution |
|--|--|---|
| Burner failure | Burner transmits error signal to PLC. The burner may have various faults. | Reset can be done with the button on the burner, detection of the fault is described in chapter 17.2 Burner faults and table. |
| Maximum boiler temperature reached | Maximum thermostat is enabled by an internal temperature of >110°C | Trace the cause of the excessive temperature. Reset the maximum thermostat inside the switch box. |
| Boiler temperature sensor broken P.TFI | Temperature is out of the usual range. | Check the connections. Replace the sensor. |
| Boiler temperature sensor broken P.TRI | Temperature is out of the usual range. | Check the connections. Replace the sensor. |
| Boiler temperature sensor broken S.TFI | Temperature is out of the usual range. | Check the connections. Replace the sensor. |
| Boiler temperature sensor broken S.TRt | Temperature is out of the usual range. | Check the connections. Replace the sensor. |



16.2 Burner faults

| SIGNAL | PROBLEM |
|--|--|
| None | The burner does not start. |
| POSSIBLE CAUSE | ADVICE |
| 1 - No power supply..... | Close all the switches. Check the plugs. |
| 2 - A limit or safety check has been opened..... | Adjust or replace them. |
| 3 - Locking of the control box..... | Reset the switch box (not earlier than 10s after locking). |
| 4 - Pump is stuck..... | Replace. |
| 5 - Incorrect electrical connections..... | Check connections. |
| 6 - Defective switch box..... | Replace. |
| 7 - Defective electric motor..... | Replace. |

| SIGNAL | PROBLEM |
|---|---|
| 2x flashing ● ● | After the pre-rinsing and safety time, the burner becomes locked. |
| POSSIBLE CAUSE | ADVICE |
| 9 - No fuel in tank; water on bottom of tank..... | Fill with fuel or suction up water. |
| 10 - Incorrect adjustment of head and air valve..... | Adjust. |
| 11 - Solenoid valves don't open..... (1st stage or safety) | Check connections; replace coil. |
| 12 - 1st nozzle clogged, dirty or deformed..... | Replace. |
| 13 - Dirty or poorly adjusted burner electrodes..... | Adjust or clean. |
| 14 - Earthed electrode due to defective insulation.... | Replace. |
| 15 - High-voltage cable defective or earthed..... | Replace. |
| 16 - High-voltage cable deformed due to high..... temperature. | Replace and protect. |
| 17 - Ignition transformer defective..... | Replace. |
| 18 - Incorrect electrical connections of valves..... or transformer. | Check. |
| 19 - Control box defective..... | Replace. |
| 20 - Pump not primed..... | Fill the pump and see: "Pump unprimes". |
| 21 - Pump/motor coupling defective..... | Replace. |
| 22 - Suction line pump connected to return line..... | Correct the connection. |
| 23 - Valves upstream of pump closed..... | Open it. |
| 24 - Dirty filters: pipe - pump - nozzle..... | Clean. |
| 25 - Defective photocell or switch box..... | Replace photocell or switch box. |
| 26 - Dirty photocell..... | Clean. |
| 27 - 1st stage of cylinder is defective..... | Replace the cylinder. |
| 28 - Motor protection triggered..... | Reset the thermal protection. |
| 29 - Defective motor control..... | Replace. |
| 30 - Missing phase. Thermal protection is switched.. | Reset the thermal protection when the third phase is reconnected. |
| 31 - Wrong direction of rotation of the motor..... | Change the motor's electrical connections. |

| SIGNAL | PROBLEM |
|---|--|
| 4x flashing ● ● ● ● | The burner starts and then becomes locked. |
| POSSIBLE CAUSE | ADVICE |
| 32 - Photocell short-circuit..... | Replace photocell |
| 33 - Light goes inside or flame is simulated..... | Eliminate light or replace control box |

| SIGNAL | PROBLEM |
|--|----------------------------------|
| 7x flashing ● ● ● ● ● ● ● | Flame detachment |
| POSSIBLE CAUSE | ADVICE |
| 34 - Badly adjusted head..... | Adjust. |
| 35 - Badly adjusted or dirty..... ignition electrodes. | Adjust. |
| 36 - Badly adjusted fan air gate: too much air. | Adjust |
| 37 - 1st nozzle too large (pulsation)..... | Reduce 1st nozzle |
| 38 - 1st nozzle too small (flame loss)..... | Increase 1st nozzle |
| 39 - 1st nozzle dirty or deformed..... | Replace |
| 40 - Unsuitable pump pressure..... | Adjust to between 10 and 14 bar. |
| 41 - 1st stage nozzle unsuitable for burner or..... boiler. | Reduce 1st stage |
| 42 - Defective nozzle 1st stage..... | Replace |

| SIGNAL | PROBLEM |
|--|---|
| 7x flashing ● ● ● ● ● ● ● | The burner does not switch to the 2nd stage |
| POSSIBLE CAUSE | ADVICE |
| 43 - Control device TR does not close..... | Adjust or replace |
| 44 - Defective switch box..... | Replace |
| 45 - Sol. valve spool 2nd stage defective..... | Replace |
| 46 - Piston jammed in valve unit. | Replace entire unit |

| SIGNAL | PROBLEM |
|--|--|
| 7x flashing ● ● ● ● ● ● ● | The fuel goes to the second stage, but the air remains in the first stage. |
| POSSIBLE CAUSE | ADVICE |
| 47 - Low pump pressure..... | Increase |
| 48 - 2nd stage operation of cylinder is defective..... | Replace the cylinder |



| SIGNAL | PROBLEM |
|---------------------------|--|
| 7x flashing ● ● ● ● ● ● ● | Burner stops in transition between 1st and 2nd phases. Burner repeats the start cycle. |
| POSSIBLE CAUSE | ADVICE |
| 49 - Nozzle dirty..... | Replace the nozzle |
| 50 - Photocell dirty..... | Clean |
| 51 - Excessive air..... | Reduce |

| SIGNAL | PROBLEM |
|--|--|
| 7x flashing ● ● ● ● ● ● ● | Uneven fuel supply |
| POSSIBLE CAUSE | ADVICE |
| 52 - Check whether the cause is in the pump or the fuel supply system. | Burner power supply from tank near burner. |

| SIGNAL | PROBLEM |
|---------------------------|---|
| 7x flashing ● ● ● ● ● ● ● | Internally corroded pump |
| POSSIBLE CAUSE | ADVICE |
| 53 - Water in tank pump | Suction water from bottom of tank with a separate pump. |

| SIGNAL | PROBLEM |
|---|--------------------------------|
| 7x flashing ● ● ● ● ● ● ● | Noisy pump, unstable pressure |
| POSSIBLE CAUSE | ADVICE |
| 54 - Air has entered the suction line..... - Pressure value too high (above 35 cm Hg): | Tighten the connectors. |
| 55 - Tank/burner height difference too great..... | Feed burner with loop circuit. |
| 56 - Pipe diameter too small..... | Increase. |
| 57 - Suction filters clogged..... | Clean. |
| 58 - Suction valves closed..... | Open. |
| 59 - Fuel solidified by low temperature..... | Add additive to the fuel. |

| SIGNAL | PROBLEM |
|--|--|
| 7x flashing ● ● ● ● ● ● ● | Pump cuts out after a prolonged pause. |
| POSSIBLE CAUSE | ADVICE |
| 60 - Return pipe not immersed in fuel..... | Move it to the same height as the suction pipe |
| 61 - Air enters suction line..... | Tighten the couplings. |

| SIGNAL | PROBLEM |
|--------------------------------|-----------------------|
| 7x flashing ● ● ● ● ● ● ● | Pump is leaking fuel. |
| POSSIBLE CAUSE | ADVICE |
| 62 - Leakage of sealing member | Replace pump. |

| SIGNAL | PROBLEM |
|---|-------------------------------------|
| 7x flashing ● ● ● ● ● ● ● | Smoke in flames - Dark Bacharach |
| POSSIBLE CAUSE | ADVICE |
| 63 - Not enough air..... | Adjust head and fan gate. |
| 64 - Nozzle worn or dirty..... | Replace |
| 65 - Nozzle filter clogged..... | Clean or replace |
| 66 - Incorrect pump pressure..... | Adjust to 10 - 14 bar |
| 67 - Flame stability coil dirty, loose or deformed..... | Clean, tighten or replace |
| 68 - Insufficient air openings in the boiler space..... | Increase |
| 69 - Excessive air..... | Adjust head and fan gate. |

| SIGNAL | PROBLEM |
|---|----------------------------------|
| 7x flashing ● ● ● ● ● ● ● | Dirty burner head |
| POSSIBLE CAUSE | ADVICE |
| 70 - Nozzle or filter dirty..... | Replace. |
| 71 - Unsuitable nozzle or angle..... | See recommended nozzles. |
| 72 - Loose nozzle..... | Tighten. |
| 73 - Impurities on flame stability coil..... | Clean. |
| 74 - Incorrect head adjustment or not enough air..... | Adjust. Open valve. |
| 75 - Length of nozzle not adapted to boiler..... | Contact the boiler manufacturer. |

| SIGNAL | PROBLEM |
|--|--|
| 10x flashing ● ● ● ● ● ● ● ● ● ● | The burner becomes locked. |
| POSSIBLE CAUSE | ADVICE |
| 76 - Connection or internal fault..... | |
| 77 - Presence of electromagnetic interference..... | Use the radio interference protection kit. |



16.3 Other faults

| Description | Cause | Solution |
|--|---|--|
| Poor flow through the secondary circuit | Dirty water filter | Clean the water filter in the secondary circuit. |
| Regular overheating of the boiler >110°C | Poor flow in the primary circuit | Check circulation pump for blockage; replace circulation pump if necessary. |
| Scraping or squealing noises in oil pump | Excessive resistance in the diesel supply circuit. Excessive dirt in filters or closed tap on oil supply. | Check the pipes for blockages. Clean the oil filter and clean the pump filter. Clean the fuel tank if heavily soiled. |
| Fluctuating secondary circuit supply temperature | PID control disrupted. | Adjust PID control or activate an auto tune. |
| Black smoke from flue gas discharge | Bad combustion with too little oxygen and too high a CO2 value | Open the air slide on the burner until the black smoke disappears. Use a flue gas meter to analyze the flue gases and re-adjust the burner to a CO2 value of 12.5% |
| White smoke from flue gas exhaust | Poor combustion due to excessive air in the fuel. | Check the oil supply for leaks. |
| White vapor from flue gas discharge | Cold flue gases during startup or boiler temperature set too low. | Increase boiler temperature to minimum 45°C. Wait 15 minutes for boiler to heat up. |

17 ENVIRONMENT

17.1 Antifreeze (Propylene Glycol)

As an option, use can be made of Propylene glycol (maximum 30%) as antifreeze in the boiler circuit. Propylene glycol has lower toxicity than other anti-freezes and is more environmentally friendly. However, liquid from the boiler must always be disposed of according to local regulations. See the supplied safety sheet "Propylene glycol".

18 DISMANTLING AND DISPOSAL

All materials released during the dismantling of this machine must be disposed of according to local government regulations.

19 EC DECLARATION OF CONFORMITY

The EC Declaration of Conformity can be found at www.thermobile.com.

[illegible]

[illegible]

© 2025 Thermobile Industries B.V.

Alle rechten voorbehouden. De verstrekte informatie mag niet worden verveelvoudigd en/of openbaar gemaakt op welke wijze dan ook (elektronisch of mechanisch), zonder schriftelijke toestemming van Thermobile Industries B.V. Thermobile Industries B.V. kan niet aansprakelijk worden gesteld voor schade die voortkomt of verband houdt met afwijkingen in deze handleiding.

© 2025 Thermobile Industries B.V.

All rights reserved. The available information has been prepared to a high level of care, but Thermobile Industries B.V. cannot be held liable for possible errors in the information or the consequences thereof. The information provided herein may not be reproduced and/or published in any form, by print, (electronically or mechanically) without the prior written authorisation of Thermobile Industries B.V.

© 2025 Thermobile Industries B.V.

Alle Rechte vorbehalten. Die verfügbare Information wurde mit großer Sorgfalt vorbereitet. Thermobile Industries B.V. kann jedoch für eventuelle Fehler in der Information oder den Konsequenzen daraus nicht haftbar gemacht werden. Die gelieferte Information darf ohne die vorherige schriftliche Genehmigung von Thermobile Industries B.V. weder reproduziert, noch in irgendeiner Weise durch Drucken (elektronisch oder mechanisch) veröffentlicht werden.

© 2025 Thermobile Industries B.V.

Tous les droits réservés. L'ensemble des informations disponibles a été préparé avec un soin extrême. Cependant, Thermobile Industries B.V. décline toute responsabilité à l'égard des erreurs possibles ou de leurs conséquences. Les informations fournies ici ne peuvent être reproduites ou publiées sous quelque forme que ce soit, voire imprimées (électroniquement ou mécaniquement) sans l'autorisation écrite préalable de Thermobile Industries B.V.

THERMOBILE INDUSTRIES BV

Konijnenberg 80
4825 BD Breda
The Netherlands

T +31 (0)76 587 34 50

info@thermobile.com
www.thermobile.com

THERMOBILE UK LTD

12, Buckingham Close
Bermuda Industrial Estate
Nuneaton, Warwickshire
CV10 7JT
Great Britain

T +44 (0)2476 35 79 60
F +44 (0)2476 35 79 69

info@thermobile.co.uk
www.thermobile.co.uk

THERMOBILE FRANCE sarl

3, rue Denis Papin
45240 LA FERTÉ ST. AUBIN
France

T +33 (0)2 38 76 59 25

info@thermobile.fr
www.thermobile.fr

Member of



the Honing Beheer Group of Companies

